

Chrome OS Quick Reference

Developer Mode

1. Turn Chromebook off
2. Press and hold Esc and Refresh screen
3. Press Power button (keeping Esc and Refresh down)
4. At recovery screen, press Ctl-D
5. Press Enter at "OS Verification OFF"
6. Chromebook reboots
7. Press Ctl-D on boot, or wait for the timeout

Factory Reset

1. Sign out (be at sign-in screen)
2. Press and hold Ctl+Alt+Shift+r
3. At prompt, select Restart, then Powerwash

From:

<https://wiki.linuxservertech.com/> - **Unix Server Tech Knowledge Base**

Permanent link:

<https://wiki.linuxservertech.com/unix/chromeos/quicktricks>

Last update: **2025/01/17 23:10**

