

opnSense NUT Client

There is some pretty good documentation at <https://docs.opnsense.org/manual/how-tos/nut.html>, though a few things caught me. I'm writing this up as a short recipe; see that documentation for the real way to do things.

Recipe

1. Install the NUT client by going to System | Firmware and installing os-nut
2. Configure at Services | Nut | Configuration (you may need to hit a different page to update your menu, I click on Lobby first)
3. General Settings
 1. Enable Nut
 2. Service Mode: netclient
 3. Name: the name *on the nut server* of the ups. Do not put the server name here, just the stuff before the @
 4. Listen Address: The IP *on the router* that has the interface you want to listen on. Probably your LAN IP.
4. Click down arrow on UPS Type and select Netclient
 1. Enable netclient
 2. IP Address: IP of the NUT server
 3. Port: Port the NUT server is listening on
 4. Username: the user name you have defined on the NUT server
 5. Password: the password you have defined on the NUT server
5. Click Apply
6. Click Diagnostics and wait up to 20 seconds. If everything is correct, you will see a list of variables from the UPS (as given by the NUT server).

Caveats

The opnSense NUT client has a lot of presets. For example, it is designed to shut down the firewall when LOWBATT is detected (I think at ups.status), which is generally set to about 10%.

opnSense logs problems to /var/log/system/latest.log with a process name of upsmon. So, the command

```
grep upsmon /var/log/system/latest.log
```

will show any issues.

The configuration files are stored in /usr/local/etc/nut, so you can actually make manual edits there, but they are not guaranteed to survive an update. upsmon.conf appears to be the only configuration file with anything in it (other than comments) when you are set up as a netclient

From:

<https://wiki.linuxservertech.com/> - **Unix Server Tech Knowledge Base**

Permanent link:

<https://wiki.linuxservertech.com/software/nut/opnsenseclient>

Last update: **2025/04/15 04:41**

